IPERLUX®

MANUALE D'ISTRUZIONI

PLAFONIERA LED IP40 3CCT REGOLABILE



STOCCOLMA

Specifiche tecniche:

	MISURE	W	Lumen	AC/Hz	3CCT (SWITCH)	CRI	TEMP. LAVORO	FINITURA	FLICKER	DIMM.	CLASSE	IK
IPC22IRBS	Ø230*30mm	22	2300	AC180-250V Hz 50/60	da 2700K a 6500K	80	-20°+50°	BIANCO	FREE	Si	II	06
IPC22IRNS	Ø230*30mm	22	2300	AC180-250V Hz 50/60	da 2700K a 6500K	80	-20°+50°	NERO	FREE	Si	II	06
IPC32IRBS	Ø300*30mm	32	3400	AC180-250V Hz 50/60	da 2700K a 6500K	80	-20°+50°	BIANCO	FREE	Si	II	06
IPC32IRNS	Ø300*30mm	32	3400	AC180-250V Hz 50/60	da 2700K a 6500K	80	-20°+50°	NERO	FREE	Si	II	06
IPC40IRBS	Ø400*30mm	40	4300	AC180-250V Hz 50/60	da 2700K a 6500K	80	-20°+50°	BIANCO	FREE	Si	II	06
IPC40IRNS	Ø400*30mm	40	4300	AC180-250V Hz 50/60	da 2700K a 6500K	80	-20°+50°	NERO	FREE	Si	II	06
IPC50IRBS	Ø500*30mm	50	5400	AC180-250V Hz 50/60	da 2700K a 6500K	80	-20°+50°	BIANCO	FREE	Si	II	06
IPC50IRNS	Ø500*30mm	50	5400	AC180-250V Hz 50/60	da 2700K a 6500K	80	-20°+50°	NERO	FREE	Si	II	06

Corpo e lente in policarbonato autoestinguente V2, resistente alla prova del filo per 650°C.
Disponibile in due finiture: bianco e nero. Resistente agli urti.
Memory function e quattro modalità di accensione: solo luce posteriore, solo luce frontale, sia luce frontale che luce posteriore, luce notturna o posteriore o frontale.
Telecomando e supporto porta telecomando a parete inclusi.


⚠ ATTENZIONE

Si raccomanda di rivolgersi a un elettricista qualificato per installare il prodotto.


Si raccomanda di non toccare il prodotto quando è acceso.

In caso di malfunzionamento, staccare la lampada dall'alimentazione.
Si raccomanda di rivolgersi a un elettricista e di non provare a riparare la lampada da soli.


MONTAGGIO




1. Scollegare la corrente elettrica.




2. Installare la parte posteriore della lampada al soffitto.




3. Collegare i cavi L e N.



4. Installare la lampada.





Informazioni sul riciclaggio in conformità con le direttive RAAE e batterie



Simbolo sul prodotto



Simbolo sulla batteria

Solo Europa

Il prodotto/batteria è contrassegnato con uno dei simboli di riciclaggio sopra indicati. Questo indica che a fine vita il prodotto/batteria, dovrà essere smaltito/a separatamente in appropriati luoghi di raccolta e non con i normali rifiuti domestici.

CE RoHs

IPERLUX®
www.iperlux.com
info@iperlux.com

IPERLUX®

INSTRUCTION MANUAL

CHANGEABLE LED CCT CAILING LAMP IP40



STOCCOLMA

Specifications and Technical Data sheet:

	SIZE	W	Lumen	AC/Hz	3CCT (SWITCH)	CRI	AMB. TEMP.	FINISH	FLICKER	DIMM.	CLASS	IK
IPC22IRBS	Ø230*30mm	22	2300	AC180-250V Hz 50/60	from 2700K to 6500K	80	-20°+50°	WHITE	FREE	Yes	II	06
IPC22IRNS	Ø230*30mm	22	2300	AC180-250V Hz 50/60	from 2700K to 6500K	80	-20°+50°	BLACK	FREE	Yes	II	06
IPC32IRBS	Ø300*30mm	32	3400	AC180-250V Hz 50/60	from 2700K to 6500K	80	-20°+50°	WHITE	FREE	Yes	II	06
IPC32IRNS	Ø300*30mm	32	3400	AC180-250V Hz 50/60	from 2700K to 6500K	80	-20°+50°	BLACK	FREE	Yes	II	06
IPC40IRBS	Ø400*30mm	40	4300	AC180-250V Hz 50/60	from 2700K to 6500K	80	-20°+50°	WHITE	FREE	Yes	II	06
IPC40IRNS	Ø400*30mm	40	4300	AC180-250V Hz 50/60	from 2700K to 6500K	80	-20°+50°	BLACK	FREE	Yes	II	06
IPC50IRBS	Ø500*30mm	50	5400	AC180-250V Hz 50/60	from 2700K to 6500K	80	-20°+50°	WHITE	FREE	Yes	II	06
IPC50IRNS	Ø500*30mm	50	5400	AC180-250V Hz 50/60	from 2700K to 6500K	80	-20°+50°	BLACK	FREE	Yes	II	06

V2 self-extinguishing PC housing and cover. Glow wire tested at 650°C. Available in two fi nishes: white and black. Resistant to impacts.
Memory function and four modes: back light only, front light only, back and front light, nightlight or front or back. Remote controller and wall remote controller holder included.


⚠ WARNING

It is recommended to contact a qualified electrician to install the product.


It is recommended not to touch the product when it is turned on.

In case of malfunction, disconnect the lamp from the power supply.
It is recommended to contact an electrician and not try to repair the lamp yourself.


MOUNTING




1. Switch off the power.




2. Screw the fastened fixture.




3. Connect the L and N cables.



4. Install the lamp.





Recycling Information in Accordance with the WEEE and Battery Directives

Product Mark Battery Mark

Europe only

The product/battery is marked with one of the above recycling symbols. It indicates that at the end of the life of the product/battery, you should dispose of it separately at an appropriate collection point and not place it in normal domestic waste steam.

CE RoHs

IPERLUX®
www.iperlux.com
info@iperlux.com