

MANUALE D'ISTRUZIONI

DENIS SEGNAPASSO IP65



Specifiche tecniche:

	MISURE	W	Lumen	AC/Hz	3CCT (SWITCH)	CRI	α	TEMP. LAVORO	FINITURA	FLICKER	DIMM.	CLASSE	IK
IPNWF6BS	228*79*28mm	6	500	AC180-250V Hz 50/60	3000/4000/6500K	80	100°	-20°+50°	BIANCO	FREE	NO	II	08
IPNWF6CS	228*79*28mm	6	500	AC180-250V Hz 50/60	3000/4000/6500K	80	100°	-20°+50°	CORTEN	FREE	NO	II	08
IPNWF6NS	228*79*28mm	6	500	AC180-250V Hz 50/60	3000/4000/6500K	80	100°	-20°+50°	NERO	FREE	NO	II	08

Segnapasso per l'illuminazione decorativa di zone di passaggio e scale. Corpo e diffusore V2 autoestinguente e Anti-UV in policarbonato termoplastico e staffa in lega di alluminio. Disponibile in tre finiture: bianco, nero e corten. Resistente agli urti.

1


ATTENZIONE

Si raccomanda di rivolgersi a un elettricista qualificato per installare il prodotto.


Si raccomanda di non toccare il prodotto quando è acceso.

In caso di malfunzionamento, staccare la lampada dall'alimentazione. Si raccomanda di rivolgersi a un elettricista e di non provare a riparare la lampada da soli.


MONTAGGIO





1. Scollegare la corrente elettrica.




2. Separare la cover dal corpo della lampada.



3. Montare il corpo della lampada al muro e collegare il cavo della corrente.



4. Fissare la cover al corpo della lampada.



5. La lampada è pronta all'uso.

Informazioni sul riciclaggio in conformità con le direttive RAAE e batterie



Simbolo sul prodotto




Simbolo sulla batteria

Solo Europa

Il prodotto/batteria è contrassegnato con uno dei simboli di riciclaggio sopra indicati. Questo indica che a fine vita il prodotto/batteria, dovrà essere smaltito/a separatamente in appropriati luoghi di raccolta e non con i normali rifiuti domestici.

CE RoHS



IPERLUX®
www.iperlux.com
info@iperlux.com

INSTRUCTION MANUAL

DENIS STEP MARKER IP65




⚠ WARNING

It is recommended to contact a qualified electrician to install the product.


It is recommended not to touch the product when it is turned on.

In case of malfunction, disconnect the lamp from the power supply. It is recommended to contact an electrician and not try to repair the lamp yourself.

MOUNTING



1. Switch off the power.



2. Separate the cover from the body.


Specifications and Technical Data sheet:

	SIZE	W	Lumen	AC/Hz	3CCT (SWITCH)	CRI	α	AMB. TEMPR.	FINISH	FLICKER	DIMM.	CLASS	IK
IPNWF6BS	228*79*28mm	6	500	AC180-250V Hz 50/60	3000/4000/6500K	80	100°	-20°+50°	WHITE	FREE	NO	II	08
IPNWF6CS	228*79*28mm	6	500	AC180-250V Hz 50/60	3000/4000/6500K	80	100°	-20°+50°	CORTEN	FREE	NO	II	08
IPNWF6NS	228*79*28mm	6	500	AC180-250V Hz 50/60	3000/4000/6500K	80	100°	-20°+50°	BLACK	FREE	NO	II	08



Step marker ideal for transit areas and stairs.
ANTI-UV and V2 Self-extinguishing thermoplastic PC housing and diffusor and aluminium alloy bracket.
Available in three finishes: white, black and corten.
Resistant to impacts.

1


2



3. Mount the case to the wall and connect the power cable.



4. Attach the body to the cover.



5. Fixture is ready to use.

Recycling Information in Accordance with the WEEE and Battery Directives



Product Mark




Battery Mark

Europe only

The product/battery is marked with one of the above recycling symbols. It indicates that at the end of the life of the product/battery, you should dispose of it separately at an appropriate collection point and not place it in normal domestic waste stream.

CE RoHs



IPERLUX®
www.iperlux.com
info@iperlux.com