



⚠ ATTENZIONE

Si raccomanda di rivolgersi a un elettricista qualificato per installare il prodotto.

Si raccomanda di non toccare il prodotto quando è acceso.

In caso di malfunzionamento, staccare la lampada dall'alimentazione. Si raccomanda di rivolgersi a un elettricista e di non provare a riparare la lampada da soli.

MANUALE D'ISTRUZIONI APPLIQUE LED 3CCT IP65



MILOS

MYKONOS


Specifiche tecniche:

	MISURE	W	Lumen	AC/Hz	3CCT (SWITCH)	CRI	α	TEMP. LAVORO	FINITURA	FLICKER	DIMM.	CLASSE	IK
IPC18RNS	99*78*162mm	18	1600	AC180-250V Hz 50/60	3000/4000/6500K	80	38°	-20°+40°	NERO	FREE	NO	II	08
IPC18RBS	99*78*162mm	18	1600	AC180-250V Hz 50/60	3000/4000/6500K	80	38°	-20°+40°	BIANCO	FREE	NO	II	08
IPC18RCS	99*78*162mm	18	1600	AC180-250V Hz 50/60	3000/4000/6500K	80	38°	-20°+40°	CORTEN	FREE	NO	II	08
IPC18QNS	99*78*162mm	18	1600	AC180-250V Hz 50/60	3000/4000/6500K	80	38°	-20°+40°	NERO	FREE	NO	II	08
IPC18QBS	99*78*162mm	18	1600	AC180-250V Hz 50/60	3000/4000/6500K	80	38°	-20°+40°	BIANCO	FREE	NO	II	08
IPC18QCS	99*78*162mm	18	1600	AC180-250V Hz 50/60	3000/4000/6500K	80	38°	-20°+40°	CORTEN	FREE	NO	II	08


Applique LED up&down rotonde e quadrate.
Corpo e diffusore V2 autoestinguento e Anti-UV in policarbonato termoplastico e staffa in lega di alluminio. Disponibile in tre finiture: bianca, nera e corten. Resistente agli urti.

1


MONTAGGIO




1. Scollegare la corrente elettrica.




2. Effettuare i fori sul muro in base alla posizione del foro della staffa, posizionare la vite di espansione.




3. Scegliere la temperatura di utilizzo, connettere il cavo all'alimentazione.



4. Fissare la lampada alla staffa.



5. Accendere l'alimentazione dopo aver installato la lampada.



Informazioni sul riciclaggio in conformità con le direttive RAAE e batterie



Simbolo sul prodotto




Simbolo sulla batteria

Solo Europa

Il prodotto/batteria è contrassegnato con uno dei simboli di riciclaggio sopra indicati. Questo indica che a fine vita il prodotto/batteria, dovrà essere smaltito/a separatamente in appropriati luoghi di raccolta e non con i normali rifiuti domestici.

CE RoHs



IPERLUX®
www.iperlux.com
info@iperlux.com

INSTRUCTION MANUAL CCT LED APPLIQUE IP65

It is recommended to contact a qualified electrician to install the product.

It is recommended not to touch the product when it is turned on.

In case of malfunction, disconnect the lamp from the power supply. It is recommended to contact an electrician and not try to repair the lamp yourself.



MILOS

MYKONOS


Specifications and Technical Data sheet:

	SIZE	W	Lumen	AC/Hz	CCT (SWITCH)	CRI	α	AMB. TEMP.	FINISH	FLICKER	DIMM.	CLASS	IK
IPC18RNS	99*78*162mm	18	1600	AC180-250V Hz 50/60	3000/4000/6500K	80	38°	-20°+40°	BLACK	FREE	NO	II	08
IPC18RBS	99*78*162mm	18	1600	AC180-250V Hz 50/60	3000/4000/6500K	80	38°	-20°+40°	WHITE	FREE	NO	II	08
IPC18RCS	99*78*162mm	18	1600	AC180-250V Hz 50/60	3000/4000/6500K	80	38°	-20°+40°	CORTEN	FREE	NO	II	08
IPC18QNS	99*78*162mm	18	1600	AC180-250V Hz 50/60	3000/4000/6500K	80	38°	-20°+40°	BLACK	FREE	NO	II	08
IPC18QBS	99*78*162mm	18	1600	AC180-250V Hz 50/60	3000/4000/6500K	80	38°	-20°+40°	WHITE	FREE	NO	II	08
IPC18QCS	99*78*162mm	18	1600	AC180-250V Hz 50/60	3000/4000/6500K	80	38°	-20°+40°	CORTEN	FREE	NO	II	08


LED Up&down applique LED round and square.

ANTI-UV and V2 Self-extinguishing thermoplastic PC housing and diffuser and aluminium alloy bracket. Available in three finishes: white, black and corten. Resistant to impacts.

MOUNTING




1. Switch off the power.



2. Trepanning on the wall according to the bracket hole position, put the expansion screw.

3. Choose the CCT temperature, connect the input wire to the production wire, reconnect metal bracket with fitting.



4. Fixed the lamp to the bracket.

Recycling Information in Accordance with the WEEE and Battery Directives



Product Mark




Battery Mark

Europe only

The product/battery is marked with one of the above recycling symbols. It indicates that at the end of the life of the product/battery, you should dispose of it separately at an appropriate collection point and not place it in normal domestic waste stream.

5. Switch on the power after installing the product.

CE RoHs



IPERLUX®
www.iperlux.com
info@iperlux.com